







Instruction Manual

Unique Small Single Seat Valve



ESE02232-EN6

2020-02

Original manual



www.sks-online.com

The information herein is correct at the time of issue but may be subject to change without prior notice

1. EC Declaration of Conformity	4
2. Safety	5
2.1. Important information	5
2.2. Warning signs	5
2.3. Safety precautions	6
3. Installation	8
3.1. Unpacking/Delivery	8
3.2. General installation	10
3.3. Welding	12
3.4. Recycling information	13
4. Operation	14
4.1. Operation	14
4.2. Trouble shooting	15
4.3. Recommended cleaning	16
5. Maintenance	18
5.1. General maintenance	18
5.2. Dismantling of valve	20
5.3. Valve assembly	21
5.4. Dismantling of actuator	23
5.5. Assembly of actuator	24
6. Technical data	25
6.1. Technical data	25
7. Parts list and service kits	26
7.1. Drawings	26
7.2. Small Single Seat Valve - Shut-off Valve 12.7-19mm	28
7.3. Small Single Seat Valve - Change-over Valve 12.7-19 mm	30
7.4. Small Single Seat Valve - Shut-off Valve Manual 12.7-19 mm	32
7.5. Small Single Seat Valve - Change-over Valve Manual 12.7-19 mm	34

1 EC Declaration of Conformity

Revision of Declaration of Conformity 2013-09-01

The Designated Company

Alfa Laval Kolding A/S

Company Name

Albuen 31, DK-6000 Kolding, Denmark

Address

+45 79 32 22 00

Phone No.

hereby declare that

Valve

Designation

Size: 12,7mm PN10, Size: 19mm PN10

Type

is in conformity with the following directive with amendments:

- Machinery Directive 2006/42/EC
- Pressure Equipment Directive 2014/68/EU category 1 and subjected to assessment procedure Module A.

The person authorised to compile the technical file is the signer of this document

Global Product Quality Manager
Pumps, Valves, Fittings and Tank Equipment

Title

Lars Kruse Andersen

Name

Kolding

Place

2016-06-01

Date

Signature



*Unsafe practices and other important information are emphasised in this manual.
Warnings are emphasised by means of special signs.*

2.1 Important information

Always read the manual before using the valve!

WARNING

Indicates that special procedures **must** be followed to avoid serious personal injury.

CAUTION

Indicates that special procedures **must** be followed to avoid damage to the valve.

NOTE

Indicates important information to simplify or clarify procedures.

2.2 Warning signs

General warning:



Caustic agents:



2 Safety

All warnings in this manual are summarised on this page.

Pay special attention to this instructions below so that severe personal injury and/or damage to the valve are avoided.

2.3 Safety precautions

Actuators


If support air is utilised:



- Shock in the actuator must **NEVER** occur
- Support air on high pressure actuator versions is **NOT** allowed


To prevent shock in the actuator and to prevent exceeding 10 bar product pressure, Alfa Laval recommends **NOT** to exceed 3 bar support air on the spring side in all the Unique SSV actuators.

If support air is connected always use the 3 bar air relief fittings = 9611995903.
Using the 3 bar air relief fitting also extends the service life of the actuator piston o-ring.




Pos. no. 5

For actuators, manufactured year 2005-2018, with serial number from 1000000 - 5999999 and from 200000000000 - 599999999999 always use steel adapter (pos 5) = 9614065301
Tighten torque = 30 Nm



Pos. no. 5

For actuators, manufactured year 2019 --> with serial number from 6000000 to 7000000 and from 600000000000 to 700000000000 always use steel adapter (pos 5) = 9615374701
Tighten torque = 15 Nm



Alfa Laval recommends max. 3 bar support air
Always use the "3 bar air relief fittings" on support air.
Alfa Laval article number = 9611995903

All warnings in this manual are summarised on this page.

Pay special attention to this instructions below so that severe personal injury and/or damage to the valve are avoided.

Installation:



Always read the technical data thoroughly (see chapter 6 Technical data)

Always release compressed air after use

Never touch moving parts if the actuator is supplied with compressed air

Never touch the valve or the pipelines when processing hot liquids or when sterilising

Never dismantle the valve with valve and pipelines under pressure

Never dismantle the valve when it is hot

Operation:



Never dismantle the valve with valve and pipelines under pressure

Never dismantle the valve when it is hot

Always read the technical data thoroughly (see chapter 6 Technical data)

Always release compressed air after use

Never touch the valve or the pipelines when processing hot liquids or when sterilising

Never touch moving parts if the actuator is supplied with compressed air



Always handle lye and acid with great care

Maintenance:



Always read the technical data thoroughly (see chapter 6 Technical data)

Always release compressed air after use

Never service the valve when it is hot

Never service the valve with valve and pipelines under pressure

Never stick your fingers through the valve ports if the actuator is supplied with compressed air

Never touch moving parts if the actuator is supplied with compressed air

Transportation:

Always ensure that compressed air is released

Always ensure that all connections are disconnected before attempting to remove the valve from the installation

Always drain liquid out of valves before transportation

Always use predesigned lifting points if defined

Always ensure sufficient fixing of the valve during transportation - if specially designed packaging material is available, it must be used

3 Installation

The instruction manual is part of the delivery. Study the instructions carefully.

The items refer to parts list and service kits section.

The valve is supplied as separate parts as standard (for welding).

The valve is assembled before delivery, if it is supplied with fittings.

3.1 Unpacking/Delivery

Step 1

CAUTION!

Alfa Laval cannot be held responsible for incorrect unpacking.


Check the delivery for:

1. Complete valve, shut-off valve, change-over valve, manual shut-off valve or manual change-over valve (see steps 2, 3, 4 and 5).
2. Delivery note
3. Instruction Manual.

Step 2

Shut-off valve


1. Complete actuator with bonnet
2. Lip seal (23)
3. Clamp (21)
4. Shut-off plug (25)
5. Lower valve body (30)
6. O-ring (26)
7. Threaded pin (20)
8. Sealing element (22)
9. O-ring (24)



Step 3

Change-over valve


1. Complete actuator with bonnet
2. Lip seal (23)
3. Two clamps (21)
4. Change-over plug (25)
5. Upper valve body (27)
6. Valve seat (29)
7. O-ring (26)
8. Threaded pin (20)
9. Sealing element (22)
10. O-ring (24)
11. Two o-rings (28)
12. Lower valve body (30)



Step 4

Manual Shut-off valve

1. Complete bonnet with handle, plug extension and lock hexnut
2. Clamp (21)
3. Lower valve body (30)
4. O-ring (26)
5. Lip seal (23)
6. Sealing element (22)
7. O-ring (24)
8. Threaded pin (20)
9. Shut-off plug (25)




3 Installation

*The instruction manual is part of the delivery. Study the instructions carefully.
The items refer to parts list and service kits section.
The valve is supplied as separate parts as standard (for welding).
The valve is assembled before delivery, if it is supplied with fittings.*

Step 5


Manual change-over valve

1. Complete bonnet with handle, plug extension and lock hexnut
2. Change-over plug (25).
3. Two clamps (21).
4. Upper valve body (27).
5. O-ring (26).
6. Lip seal (23).
7. Sealing element (22).
8. Valve seat (29)
9. O-ring (24)
10. Threaded pin (20)
11. Two o-rings (28)
12. Lower valve body (30)



Step 6


Remove any possible packing materials from the valve/ valve parts.



Remove packing materials!

Step 7

Inspect the valve/valve parts for visible transport damages.
Avoid damaging the valve/valve parts.



Inspection!

3 Installation

Study the instructions carefully and pay special attention to the warnings!
The valve has welding ends as standard but can also be supplied with clamp fittings.

3.2 General installation

Step 1



Always read the technical data thoroughly.
See section 6 Technical data



Always release compressed air after use.


CAUTION!

Alfa Laval cannot be held responsible for incorrect installation.

Step 2




Never touch the moving parts if the actuator is supplied with compressed air.



Step 3

It is recommended to install the valve so that the flow is against the closing direction to avoid water hammering.

Avoid water hammering!




Step 4

Avoid stressing the valve.

Pay special attention to

- Vibrations
- Thermal expansion of the tubes
- Excessive welding
- Overloading of the pipelines

Risk of damage!




Study the instructions carefully and pay special attention to the warnings!
The valve has welding ends as standard but can also be supplied with clamp fittings.

Step 5

Make sure that the leak detection hole in the valve body:

1. is visible, when mounting the valve vertically
2. always is downwards due to self-draining, when the valve is mounted horizontally.



* = Leakage detection hole

3 Installation

Study the instructions carefully.

The valve is supplied as separate parts to facilitate the welding. The items refer to the parts list and service kits section.

Check the valve for smooth operation after welding.

NO = Normally open. NC = Normally closed.


3.3 Welding

Step 1

Always weld the valve so that the seals between the valve bodies can be replaced.

Maintain the minimum clearances (A and B) so that the lower valve body and plug (change-over valve) and the actuator with the internal parts can be removed.

Valve size DN/OD	Measurements in mm (inch)		
	A	B ₁	B ₂ (incl. top unit)
12.7 mm	160 (6.3)	175 (6.9)	245 (9.7)
19 mm	175 (6.9)	180 (7.1)	250 (9.8)




Step 2

Shut-off valve/manual Shut-off valve:

Assemble the valve in accordance with the steps in section 5.3 Valve assembly.

Pay special attention to the warnings!




Step 3

Change-over valve/manual change-over valve:

Assemble the valve in accordance with the steps in section 5.3 Valve assembly.

Pay special attention to the warnings!



Remember seal rings!

Study the instructions carefully.

The valve is supplied as separate parts to facilitate the welding. The items refer to the parts list and service kits section.

Check the valve for smooth operation after welding.


NO = Normally open. NC = Normally closed.

Step 4

Pre-use check

1. Supply compressed air to the actuator.
2. Open and close the valve several times to ensure that it operates smoothly.

Pay special attention to the warnings!



3.4 Recycling information

• Unpacking

- Packing material consists of wood, plastics, cardboard boxes and in some cases metal straps
- Wood and cardboard boxes can be re-used, recycled or used for energy recovery
- Plastics should be recycled or burnt at a licensed waste incineration plant
- Metal straps should be sent for material recycling

• Maintenance

- During maintenance, oil and wearing parts in the machine are replaced
- All metal parts should be sent for material recycling
- Worn out or defective electronic parts should be sent to a licensed handler for material recycling
- Oil and all non-metal wear parts must be disposed off in agreement with local regulations

• Scrapping

- At end of use, the equipment must be recycled according to the relevant, local regulations. Besides the equipment itself, any hazardous residues from the process liquid must be considered and dealt with in a proper manner. When in doubt, or in the absence of local regulations, please contact your local Alfa Laval sales company

4 Operation

Study the instructions carefully and pay special attention to the warnings!
Ensure that the valve operates smoothly.
The items refer to the parts list and service kits section.
NO = Normally open. NC = Normally closed.

4.1 Operation

Step 1

Always read the technical data thoroughly (see chapter 5)
Always release compressed air after use.


CAUTION!

Alfa Laval cannot be held responsible for incorrect operation.

Step 2

Never touch the valve or the pipelines when processing hot liquids or when sterilizing.


Burn hazard!



Step 3

Never touch the moving parts if the actuator is supplied with compressed air.

Moving parts





Step 4

Lubrication of valves

1. Ensure smooth movement between sealing element (22), lip seal (23) and plug (25).
2. Lubricate the lip seal with silicone oil/grease if necessary.

Change-over valve

Shut-off valve




Lubricate if necessary!
(see section 5.1 General maintenance)

Pay attention to possible faults. Study the instructions carefully.
The items refer to the parts list and service kits section.

Step 5

Lubrication of actuator

1. Ensure smooth movement of the actuator (the actuator is lubricated before delivery).
2. Lubricate all seals with grease if necessary.



4.2 Trouble shooting

NOTE!

Study the maintenance instructions carefully before replacing worn parts. - See section 5.1 General maintenance!

Problem	Cause/result	Repair
The valve plug jerks	The sealings seize	Lubricate: <ul style="list-style-type: none"> - O-rings (3) - O-ring (9) and the inside of cylinder (1) - Lip seal (23)
Product leakage at stem and/or clamp	Worn/product affected lip seal (23) and/or o-ring (26/28)	<ul style="list-style-type: none"> - Replace the seals - Replace with seals of a different rubber grade
Product leakage (closed valve)	<ul style="list-style-type: none"> - Worn/product affected - Loose plug parts (vibrations) - Product deposits on the seat and/or plug 	<ul style="list-style-type: none"> - Replace the plug - Tighten the loose parts - Frequent cleaning
Product leakage (too high pressure)	<ul style="list-style-type: none"> - Worn actuator o-rings - Too weak spring 	<ul style="list-style-type: none"> - Replace the o-rings - Fit a stronger spring
Water hammer	The flow direction is the same as the closing direction	<ul style="list-style-type: none"> - The flow direction should be against the closing direction
The valve does not open/close	<ul style="list-style-type: none"> - Faulty plug/piston rod assembly - The pressure on the plug is too high 	<ul style="list-style-type: none"> - Replace o-ring (24) between plug and piston rod - Reduce the pressure

4 Operation

The valve is designed for *Cleaning In Place (= CIP)*.

Study the instructions carefully and pay special attention to the warnings!

NaOH = Caustic Soda.

HNO₃ = Nitric acid.

4.3 Recommended cleaning

Step 1



Always handle lye and acid with great care.

Caustic danger!



Always use
rubber gloves!




Always use
protective goggles!

Step 2



Never touch the valve or the pipelines when sterilising.



Burn hazard!





Step 3

Clean the plug and the seats correctly.

Pay special attention to the warnings

Shut-off valve

Change-over valve



Open!

Lift and lower momentarily (flip)!

Step 4

Examples of cleaning agents:

Use clean water, free from chlorides.

1. 1% by weight NaOH at 70° C (158°F)

1 kg (2.2 lb) NaOH	+	100 l (26.4 gal) water	= Cleaning agent.
-----------------------	---	----------------------------	-------------------

2.2 l (0.6 gal) 33% NaOH	+	100 l (26.4 gal) water	= Cleaning agent.
------------------------------	---	----------------------------	-------------------

2. 0.5% by weight HNO₃ at 70° C (158°F)

0.7 l (0.2 gal) 53% HNO ₃	+	100 l (26.4 gal) water	= Cleaning agent.
--	---	----------------------------	-------------------

The valve is designed for Cleaning In Place (= CIP).


Study the instructions carefully and pay special attention to the warnings!

NaOH = Caustic Soda.

HNO₃ = Nitric acid.

Step 5

1. Avoid excessive concentration of the cleaning agent.
⇒ **Dose gradually!**
2. Adjust the cleaning flow to the process.
⇒ **Milk sterilization/viscous liquids**
⇒ **Increase the cleaning flow!**
3. **Always** rinse well with clean water after the cleaning.



Step 6

NOTE

The cleaning agents must be stored/disposed of in accordance with current regulations/directives.

5 Maintenance

Maintain the valve regularly.

Study the instructions carefully and pay special attention to the warnings!

Always keep spare rubber seals and lip seals in stock.

5.1 General maintenance

Step 1



- **Always** read the technical data thoroughly (see 6 Technical data).
- **Always** release the compressed air after use.


NOTE!

All scrap must be stored/disposed of in accordance with current rules/directives.

Step 2



- **Never** service the valve when it is hot.
- **Never** service the valve with valve/actuator under pressure




Step 3



Never touch the the moving parts if the actuator is supplied with compressed air.



Never stick your fingers through the valve ports if the actuator is supplied with compressed air.



*Maintain the valve regularly.
Study the instructions carefully and pay special attention to the warnings!
Always keep spare rubber seals and lip seals in stock.*

Below are some guidelines for maintenance and lubrication intervals.
Please note that the guidelines are for normal working conditions.

	Valve rubber seals	Valve lip seal	Actuator rubber seals
Preventive maintenance	Replace after 12 months	Replace when replacing the rubber seals	Replace after 5 years
Maintenance after leakage (leakage normally starts slowly)	Replace at the end of the day	Replace when replacing the rubber seals	Replace when possible
Planned maintenance	<ul style="list-style-type: none"> - Regular inspection for leakage and smooth operation - Keep a record of the valve - Use the statistics for planning of inspections Replace after leakage	Replace when replacing the rubber seals	<ul style="list-style-type: none"> - Regular inspection for leakage and smooth operation - Keep a record of the actuator - Use the statistics for planning of inspections Replace after leakage
Lubrication (USDA H1 approved oil/grease)	Before fitting Silicone oil or silicone grease	Before fitting Silicone oil or silicone grease	Before fitting Oil or grease


Pre-use check:

1. Supply compressed air to the actuator.
2. Open and close the valve several times to ensure that it operates smoothly.

Pay special attention to the warnings!

Recommended spare parts

Service kits (see chapter 6).
Order service kits from the service kits list
(see chapter 7 Parts list and service kits).



5 Maintenance

Study the instructions carefully. The items refer to the parts list and service kits section.

Handle scrap correctly.

NC = Normally closed. NO = Normally open.


5.2 Dismantling of valve

Step 1

1A - Change-over valve

1. Supply compressed air to the actuator (only NC).
2. Loosen and remove lower clamp (21).
3. Remove lower valve body (30).
4. Release compressed air.


Pay special attention to the warnings!



1B - Shut-off valve

1. Supply compressed air to the actuator (only NC).
2. Loosen and remove clamp (21).
3. Lift out the actuator.
4. Release compressed air.


Pay special attention to the warnings!



Step 2

1. Supply compressed air to the actuator (only NO).
2. Remove plug (25) and o-ring (24). Use 11mm spanner and counterhold on actuator shaft.
3. Release compressed air.
4. Remove o-rings (28) from seat (only change-over).

Pay special attention to the warnings!



Shut-off valve

Change-over valve

Study the instructions carefully.


The items refer to the parts list and service kits section.

Lubricate the rubber seals and the lip seal before fitting them.

Step 3


Change-over valve

1. Remove upper clamp (21).
2. Remove upper valve body (27).



Step 4


Remove lip seal (23) and o-ring (26) from sealing element (22).



5.3 Valve assembly

Step 1

Fit lip seal (23) and o-ring (26) on sealing element (22).



5 Maintenance

Study the instructions carefully.

The items refer to the parts list and service kits section.


Lubricate the rubber seals and the lip seal before fitting them.

Step 2

Shut-off valve

1. Supply compressed air to the actuator (only NO).
2. Fit threaded pin (20) using Loctite 326 or similar glue.
3. Fit sealing element (22), plug (25) and o-ring (24).
4. Release compressed air.

Pay special attention to the warnings!




Step 3

Shut-off valve

1. Supply compressed air to the actuator (only NC).
2. Fit the actuator.
3. Fit and tighten clamp (21).
4. Release compressed air.


Pay special attention to the warnings!



Step 4

Change-over valve

1. Fit threaded pin (20) using Loctite 326 or similar glue.
2. Assemble upper valve body (27), sealing element (22) and the actuator.
3. Fit and tighten upper clamp (21).




Step 5

Change-over valve

1. Supply compressed air to the actuator (only NO).
2. Fit o-rings (28) on valve seat (29).
3. Fit valve seat (29), o-ring (24) and plug (25). Use 11 mm spanner to counterhold actuator stem.
4. Gently release compressed air (NO).
5. Supply compressed air (only NC).
6. Assemble lower and upper valve bodies (27 and 30).
7. Fit and tighten lower clamp (21).
8. Release compressed air (NC).

Pay special attention to the warnings!

Turn the diagonal surface of valve seat (29) upwards!



Study the instructions carefully.


The items refer to the parts list and service kits section. Handle scrap correctly

5.4 Dismantling of actuator

Step 1


1. Remove cylinder (1).
2. Remove lock wire (12).

Rotate by hand or with filter strap!




Step 2

1. Remove cylinder (1).
2. Remove o-rings (3, 11) from bonnet (13) and o-ring (3) from cylinder (1).




Step 3

1. Remove piston/spring package.
2. Remove o-ring (9) from the piston (10).



Step 4

Replace the rubber seals



5 Maintenance

Study the instructions carefully.


The items refer to the parts list and service kits section.

Lubricate the rubber seals before fitting them.

5.5 Assembly of actuator


Step 1

1. Fit o-ring (9) on piston (10).
2. Fit the piston/spring package.



Step 2


1. Fit o-rings (3, 11) in bonnet (13) and o-ring (3) on cylinder (1).
2. Fit the cylinder.



Step 3

1. Fit lock wire (12) through the slot in cylinder (1) into the hole in bonnet (13).
2. Rotate the cylinder 360° (see step 4).


Rotate by hand or with filter strap!



Step 4

NOTE!

It is recommended to rotate cylinder (1) further 180° in relation to bonnet (13) so that the top and bottom air connections are fixed on the same side.



*It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.*

6.1 Technical data

The valve is remote-controlled by means of compressed air or manually operated. The small single seat valve is very reliable due to its simple design and few moving parts.

Standard Design The Small Single Seat Valve comes as a pneumatic or manual operated in either a one or two body configuration.

The plug is a PVDF plug. All components are assembled by means of clamp rings, whereas the piston and valve plug have a threaded connection.

Technical data - valve/actuator	
Max. product pressure	1000 kPa (10 bar) (145 psi)
Min. product pressure	Full vacuum
Temperature range	-10°C to + 140°C (14°F to 284°F) (EPDM)
Air pressure, actuator	100 to 700 kPa (1 to 7 bar) (14.5 to 101.5 psi)
Materials - valve/actuator	
Product wetted steel parts	Acid-resistant steel 1.4404 (AISI 316L)
Finish, outside	Semi bright
Finish, inside	Ra ≤ 0.5µm
Other steel parts	Stainless steel 1.4307 (AISI 304L)
Plug	PVDF
Product wetted seals	EPDM
Actuator seals	Nitrile (NBR)
Alternative product wetted seals	HNBR and FPM

Weight (kg)

Nominal Size	Remote-controlled		Manually operated	
	DN/OD		DN/OD	
	12.7mm	19mm	12.7mm	19mm
Weight (kg) - Shut-off valve	1.07	1.10	0.5	0.53
Weight (kg) - Change-over valve	1.36	1.41	0.8	0.85

Noise


One meter away from - and 1.6 meter above the exhaust the noise level of a valve actuator will be approximately 77db(A) without noise damper and approximately 72 db(A) with damper - Measured at 7 bars air-pressure.

7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.*


7.1 Drawings

See parts list in section 7.2 Small Single Seat Valve - Shut-off
Valve 12.7-19mm



**Small Single Seat Valve
Shut-off Valve DN/OD12.7-19mm**

See parts list in section 7.3 Small Single Seat Valve -
Change-over Valve 12.7-19 mm




**Small Single Seat Valve
Change-Over Valve DN/OD12.7-19mm**

7 Parts list and service kits


*It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.*

See parts list in section 7.4 Small Single Seat Valve - Shut-off
Valve Manual 12.7-19 mm



Small Single Seat Valve
Manual Shut-off Valve DN/OD12.7-19mm

See parts list in section 7.5 Small Single Seat Valve -
Change-over Valve Manual 12.7-19 mm




Small Single Seat Valve
Manual Change-Over Valve DN/OD12.7-19mm

7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.*

7.2 Small Single Seat Valve - Shut-off Valve 12.7-19mm



7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.*

Parts list

Pos.	Qty	Denomination
1	1	Cylinder
2	2	Middle piece
3 □	2	O-ring
4	1	Plug
5	1	Guide pin
6	1	Piston rod
7	1	Spring
8	1	O-ring
9 □	1	O-ring
10	1	Piston
11 □	1	O-ring
12	1	Lock wire
13	1	Bonnet
14	1	Air fitting
19	2	Screw
20	1	Threaded pin
21a	1	Clamp with hexnut
21b	1	Clamp with wingnut
22	1	Sealing element
23 ♦	1	Lip seal
24 ♦	1	O-ring
25 ♦	1	Stop plug
26 ♦	1	O-ring
30	1	Lower valve body

Service kits

Denomination	12.7 mm	19 mm
Service kit for actuator		
□ Service kit, NBR	9611926323	9611926323
Service kits for product wetted parts, standard		
♦ Service kits, EPDM	9611926319	9611926330
♦ Service kits, HNBR	9611926317	9611926328
♦ Service kits, FPM	9611926318	9611926329

Parts marked with □♦ are included in the service kit.


Recommended spare parts: service kits.

TD 900218/1

7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.*

7.3 Small Single Seat Valve - Change-over Valve 12.7-19 mm



7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.*

Parts list

Pos.	Qty	Denomination
1	1	Cylinder
2	2	Middle piece
3 □	2	O-ring
4	1	Plug
5	1	Guide pin
6	1	Piston rod
7	1	Spring
8	1	O-ring
9 □	1	O-ring
10	1	Piston
11 □	1	O-ring
12	1	Lock wire
13	1	Bonnet
14	1	Air fitting
19	2	Screw
20	1	Threaded pin
21a	2	Clamp with hexnut
21b	2	Clamp with wingnut
22	1	Sealing element
23 ♦	1	Lip seal
24 ♦	1	O-ring
25 ♦	1	Change-over plug
26 ♦	1	O-ring
27	1	Upper valve body
28 ♦	2	O-ring
29	1	Valve seat
30	1	Lower valve body

Service kits

Denomination	12.7 mm	19 mm
Service kits for actuator		
□ Service kit, NBR	9611926323	9611926323
Service kits for product wetted parts, standard		
♦ Service kits, EPDM	9611926322	9611926333
♦ Service kits, HNBR	9611926320	9611926331
♦ Service kits, FPM	9611926321	9611926332


Parts marked with □♦ are included in the service kit.
Recommended spare parts: service kits.

TD 900219/1

7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.*

7.4 Small Single Seat Valve - Shut-off Valve Manual 12.7-19 mm



7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.*

Parts list

Pos.	Qty	Denomination
15	1	Manual bonnet
16	1	Handle
17	1	Stem extension
18	1	Lock nut
20	1	Threaded pin
21a	1	Clamp with hexnut
21b	1	Clamp with wingnut
22	1	Sealing element
23 ♦	1	Lip seal
24 ♦	1	O-ring
25 ♦	1	Stop plug
26 ♦	1	O-ring
30	1	Lower valve body

Service kits

Denomination	12.7 mm	19 mm
Service kits for actuator		
□ Service kit, NBR	9611926323	9611926323
Service kits for product wetted parts, standard		
♦ Service kits, EPDM	9611926319	9611926330
♦ Service kits, HNBR	9611926317	9611926328
♦ Service kits, FPM	9611926318	9611926329


Parts marked with □♦ are included in the service kit.
Recommended spare parts: service kits.

TD 900220/1

7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.*

7.5 Small Single Seat Valve - Change-over Valve Manual 12.7-19 mm



7 Parts list and service kits

*It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.*

Parts list

Pos.	Qty	Denomination
15	1	Manual bonnet
16	1	Handle
17	1	Stem extension
18	1	Lock nut
20	1	Threaded pin
21a	2	Clamp with hexnut
21b	2	Clamp with wingnut
22	1	Sealing element
23 ♦	1	Lip seal
24 ♦	1	O-ring
25 ♦	1	Change-over plug
26 ♦	1	O-ring
27	1	Upper valve body
28 ♦	2	O-ring
29	1	Valve seat
30	1	Lower valve body

Service kits

Denomination		12.7 mm	19 mm
Service kits for actuator			
□	Service kit, NBR	9611926323	9611926323
Service kits for product wetted parts, standard			
♦	Service kits, EPDM	9611926322	9611926333
♦	Service kits, HNBR	9611926320	9611926331
♦	Service kits, FPM	9611926321	9611926332

Parts marked with □♦ are included in the service kit.
Recommended spare parts: service kits.

TD 900221/1

How to contact Alfa Laval

Contact details for all countries are continually updated on our website.

Please visit www.alfalaval.com to access the information directly.

© Alfa Laval Corporate AB

This document and its contents is owned by Alfa Laval Corporate AB and protected by laws governing intellectual property and thereto related rights. It is the responsibility of the user of this document to comply with all applicable intellectual property laws. Without limiting any rights related to this document, no part of this document may be copied, reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the expressed permission of Alfa Laval Corporate AB. Alfa Laval Corporate AB will enforce its rights related to this document to the fullest extent of the law, including the seeking of criminal prosecution.